CommandCentral AXS Console

Radio dispatch for the modern world

As a dispatcher, when every second counts, it's your job to provide crucial intelligence to personnel and to keep people safe. Yet in today's world, you have more information, resources and tools competing for your attention than ever.





Built to work the way you do

Precious time is lost if you have to switch between folders and elements across multiple screens to collect and process data from disparate sources. That's why we created the CommandCentral AXS Console. Based on extensive observation of the way dispatchers work, it has been thoughtfully designed to help you confidently and efficiently manage any situation that comes your way.

With a resource-centric design and the flexibility to interact by touch, type or click, you can stay connected to your team in the way that suits you best. Configure and deploy CommandCentral AXS based on your needs – not ours – and know it can grow with your organization for years to come. Whether for a planned event or emergency response, AXS can provide full remote dispatch capability when operating outside your radio network with Internet access.

Next generation dispatch experience

With CommandCentral AXS, you can access what you want, where you want, in the manner you want. Important tasks and frequently used functions are located directly within each resource, helping telecommunicators think fast and respond faster during pressure-packed moments. Easy-to-customize controls, virtually unlimited resource folders, and a frequently used functions toolbar lets you configure screens for multiple deployment requirements, from main and backup sites to mutual aid scenarios. And when paired with other CommandCentral solutions that have the same visual appearance and way of operating, AXS can help you shave precious time off lengthy training requirements.

Tailor any additional services and expert support based on your agency's unique needs. Choose from a wide range of options, including on-site tech support, scheduled preventative maintenance, equipment repair and return, and cybersecurity Managed Detection and Response (MDR) services for 24/7 protection against cyber threats like ransomware.

GENERAL CONSOLE FUNCTIONALITY		
	General Transmit	
	Instant Transmit	
	APB Transmit	
	Monitor (disable CTCSS)	
	Single Select	
	Multi-Select (up to 16 groups per dispatch position)	
	All Mute	
	Acoustic Cross Mute	
	Patch (up to 16 groups per dispatch position)	
Console Functionality	Display Radio PTT ID with Alias	
Tanotionanty	Emergency Alarm	
	Call Alert	
	Time Display	
	VU Meter	
	Activity Log	
	Instant Recall Recorder	
	Integrated Paging Encoder	
	Channel Marker	
	Alert Tones (up to 15 per dispatch position, all customizable)	
Deployments	Inside the ASTRO Radio Network Infrastructure	
Options	Outside the ASTRO Radio Network Infrastructure	

SECURE VOICE SERVICES		
Algorithms	AES, DES-OFB and ADP Algorithms	
Dispatcher User Controls	Secure Mode Selection (coded / clear)	
	Key Select (conventional)	
	Multikey (conventional)	
	Momentary Key Override (conventional)	
Dispatcher User Indications	Receive Cross-Mode Indication	
	Multi-Select Cross-Mode Alert	
	Patch Cross-Mode Alert	
	Key Fail Indication	
	Clear Audio Alert	
	Key Display (conventional)	
Key Management	Key Management via Key Variable Loader	
	Key Management via Over The Ethernet Keying (OTEK)	
Key Storage	FIPS 140-2 Level 2, FIPS 140-3 Level 2 and Level 3	
Traffic Encryption	FIPS 140-2 Level 1, FIPS 140-3 Level 3	





ASTRO Trunking Talkgroup Resource ASTRO Trunking Announcement Group Resource ASTRO Trunking Individual Resource ASTRO Trunking System Wide Resource Simple Analog Conventional Resource MDC1200 Analog Conventional Resource ASTRO Conventional Resource ASTRO Trunking Talkgroup Call ASTRO Trunking Announcement Group Call ASTRO Trunking Emergency Call ASTRO Trunking Individual Call ASTRO Trunking System Wide Call Conventional PTT Call
Types of Resources ASTRO Trunking Individual Resource ASTRO Trunking System Wide Resource Simple Analog Conventional Resource MDC1200 Analog Conventional Resource ASTRO Conventional Resource ASTRO Trunking Talkgroup Call ASTRO Trunking Announcement Group Call ASTRO Trunking Emergency Call ASTRO Trunking Individual Call ASTRO Trunking System Wide Call Conventional PTT Call
Types of Resources ASTRO Trunking System Wide Resource Simple Analog Conventional Resource MDC1200 Analog Conventional Resource ASTRO Conventional Resource ASTRO Trunking Talkgroup Call ASTRO Trunking Announcement Group Call ASTRO Trunking Emergency Call ASTRO Trunking Individual Call ASTRO Trunking System Wide Call Conventional PTT Call
Resources ASTRO Trunking System Wide Resource Simple Analog Conventional Resource MDC1200 Analog Conventional Resource ASTRO Conventional Resource ASTRO Trunking Talkgroup Call ASTRO Trunking Announcement Group Call ASTRO Trunking Emergency Call ASTRO Trunking Individual Call ASTRO Trunking System Wide Call Conventional PTT Call
Simple Analog Conventional Resource MDC1200 Analog Conventional Resource ASTRO Conventional Resource ASTRO Trunking Talkgroup Call ASTRO Trunking Announcement Group Call ASTRO Trunking Emergency Call ASTRO Trunking Individual Call ASTRO Trunking System Wide Call Conventional PTT Call
ASTRO Conventional Resource ASTRO Trunking Talkgroup Call ASTRO Trunking Announcement Group Call ASTRO Trunking Emergency Call ASTRO Trunking Individual Call ASTRO Trunking System Wide Call Conventional PTT Call
ASTRO Trunking Talkgroup Call ASTRO Trunking Announcement Group Call ASTRO Trunking Emergency Call ASTRO Trunking Individual Call ASTRO Trunking System Wide Call Conventional PTT Call
ASTRO Trunking Announcement Group Call ASTRO Trunking Emergency Call ASTRO Trunking Individual Call ASTRO Trunking System Wide Call Conventional PTT Call
ASTRO Trunking Emergency Call ASTRO Trunking Individual Call ASTRO Trunking System Wide Call Conventional PTT Call
ASTRO Trunking Individual Call ASTRO Trunking System Wide Call Conventional PTT Call
Type of Calls ASTRO Trunking System Wide Call Conventional PTT Call
Type of Calls Conventional PTT Call
Conventional PTT Call
0 " 140TP0 = 0 "
Conventional ASTRO Emergency Call
Conventional MDC 1200 Emergency Call
Conventional ASTRO Voice Selective Call
Conventional MDC 1200 Voice Selective Call
Individual Resource Volume Control
Repeat Control (trunking and conventional)
Transmit Mode Control (Coded / Clear) (trunking and conventional)
System Access Priority Select (Normal / Tactical) Resource (trunking)
Controls Frequency Selection Control (conventional)
PL Selection Control (conventional)
Wildcard I and II Control (conventional)
Mute Receiver 2 Control (conventional)
Emergency Alarm (trunking and conventional)
Radio Status Request (conventional)
Radio Status Display (trunking and conventional)
Advanced Radio Message Display (conventional)
Signaling Radio Enable / Disable (conventional)
Radio Check (conventional)
Remote Monitor (trunking and conventional)
Manual Page
Pre-configured Page
Paging Group Paging
Checklist Paging

COMMANDCENTRAL HUB		
	MODEL B1955A	MODEL B1956A
Dimensions (H x W x D)	Without cable strain relief bracket: 3.5 x 17.0 x 8.8 inches, 89 x 432 x 224 mm	
	With cable strain relief bracket: 3.5 x 17.0 x 12.0 inches, 89 x 432 x 305 mm	
Weight	10.8 lbs (4.9 kg)	13 lbs (5.9 kg)
Power Consumption	170 W typical 270 W maximum	350 W typical 450 W maximum
Thermal Output	480 BTU/hr typical 887 BTU/hr maximum	580 BTU/hr typical 887 BTU/hr maximum
Operating Voltages/ Frequencies	120 VAC at 60 Hz 240 VAC at 60 Hz 120 VAC at 50 Hz 240 VAC at 50 Hz	
Operating Environment	32 to 104° F at 90% RH maximum non-condensing 0 to +40° C at 90% RH non-condensing	
Storage Environment	-4 to 140° F at 90% RH maximum non-condensing -25 to +70° C at 90% RH non-condensing	
Certifications	Safety UL/CSA 60950 (UL/CSA safety) UL/CSA 62369 with CB scheme (UL/CSA safety) EN62368-1 2014 (CE safety) Motorola Solutions R56 grounding requirements EMC Emissions & Immunity FCC part 15 Class A (US emissions for unintentional radiators) ICES-003 (Canadian emissions) EN55032 2012 (CE emissions for telecom equipment) EN55035 2017 (CE immunity for telecom equipment) EN61000-3-2 2014 (CE power line harmonics) EN61000-3-3 2013 (CE voltage fluctuations and flicker) Environmental Restriction of Hazardous Substances (RoHS) per directive 2011/65/EU and amendment 2015/863 of the European Parliament Waste Electrical and Electronics Equipment (WEEE) per directive 2012/19/EU of the European Parliament IEC 60529 rating of IP20 (Intrusion resistance to objects greater than 12.5 mm and no liquid resistance) Energy Efficiency Energy Efficiency Level VI	



AUXILIARY INPUTS AND OUTPUTS		
Public Aux I/Os	Momentary Relay	
	Latching Relay	
	Interlocked Latching Relay	
	Momentary Input	
	Latching Input	
Private Aux I/Os	Relay for Dispatch Console PTT	
	Relay for Received Emergency	
	Relay for Received Call on Selected Channel	
	Relay Closure when Global Aux I/O goes Active (for external Sonalert)	

COMMANDCENTRAL AXS ACCESSORIES		
CommandCentral Hub		
Up to 8 Speakers		
Up to 2 Headset Jacks		
1 Desk Microphone		
1 Footswitch		
1 External Paging Encoder Port		
1 Telephone / Headset Port		
1 Local Logging Ports		

HP Z2 MINI WORKSTATION	
Dimensions(HxWxD)	2.7 x 8.3 x 8.6 inches 68.58 x 210.82 x 218.44mm
Weight	5.29 lbs 2.4 kg
Power Consumption	177 W typical 250 W maximum
Thermal Output	603 BTU/hr typical 854 BTU/Hr maximum
Operating Voltages/ Frequencies	120 VAC at 60 Hz 240 VAC at 60 Hz 120 VAC at 50 Hz 240 VAC at 50 Hz
Operating Environment	41 to 95° F*
Storage Environment	-40 to 140° F*

^{*}Dispatch Position PC measurements are approximate and will vary with configuration and model of PC. Computers generally can be stored over a range of -40 to +140 degrees Fahrenheit at a maximum relative humidity of 90% noncondensing, but it is best to check the manufacturer's website for the specific model computer being used.

For more information or to learn more please visit www.motorolasolutions.com/commandcentralaxs

